


SERIES INCREMENTAL LINEAR ENCODERS



Measuring

Lengths - Always order by measuring length. See SPB datasheet for overall length.

8"

10" - Prefix the measuring length with 0's as necessary to get to 3 digit order code. Example: 8" is 008

12"

14" - Linear encoders include:16" Reader head with cable

18" Scale (Tube)

20" Scale (Tube) mounting kit # 600-83485 including 22" Round coupling (294-91080) and set screws

Flexible cable mount assy (316-82750)

- Extension cables are sold separately
- Bracket kits to mount the reader head are sold separately

Reader Head Bracket Kit

Part # Description

UBK01 Universal Bracket Kit (Mounts two SHG or SPB reader heads)

Optional Scale (Tube) Mounting Hardware

Part # Description


600-83486 Single End Mount Kit for SPB Scale (Tube)



EXTENSION CABLES

for use with

SHG-TT, SHG-TS, SHG-VV, SHG-VM, SPB-*, MHG-TT, MHG-VV, MHG-VM, & MAG-TT SERIES LINEAR ENCODERS



INPUT CONNECTOR

09D0 = 9-PIN D CONNECTOR (FEMALE)

09B0 = 12-PIN BINDER IP67 RATED CONNECTOR (FEMALE)